

OPERATOR'S INSTRUCTIONS – BARRETT WEST RINK

IMPORTANT, LOOK AT SCREEN WHILE PROGRAMMING, NOT WALL CLOCK!

*****NOTE YOUR ENTRY MUST BE DONE QUICKLY OR IT WILL TIME OUT*****

DISPLAY SCREEN

| | | | | | | | | |
|------------|---------------|-------|------------------|----------|-------|---|-------|-------------|
| HOME SCORE | VISITOR SCORE | 2:00 | GAME TIME | INT MODE | 7 | 8 | 9 | HORN |
| HOME PNLTY | VISITOR PNLTY | 5:00 | NEW GAME | PERIOD | 4 | 5 | 6 | |
| HOME SHOTS | VISITOR SHOTS | 10:00 | PLAY TIMER SET | SHIFT | 1 | 2 | 3 | RUN STOP |
| + 1 | RENTAL TIME | 20:00 | PLAY TIMER RESET | SETUP | CLEAR | 0 | ENTER | |

TO SET TIME CLOCK

1. PRESS "GAME TIME"
2. ENTER "CLR, CLR, CLR" TO CLEAR OLD ENTRY
3. ENTER TIME YOU NEED AS 2 OR 15 OR 20
4. PRESS "ENTER" NOTE TIMER MUST DISPLAY DOWN, PUSH "NEW GAME" TO CHANGE SETTING

TO SET PERIOD

1. PRESS "PERIOD"
2. ENTER PERIOD NUMBER "1" OR "2"
3. PRESS "ENTER"

TO SET GOALS

1. PRESS "HOME" OR "VISITOR SCORE"
2. PRESS "+1" AFTER EACH GOAL SCORED

TO SET SHOT CLOCK

1. PRESS "PLAY TIMER SET"
 2. ENTER "30" THEN PRESS "ENTER"
- Note there is no remote for this clock it is done on the control box by pressing "PLAY TIMER RESET" every time the referee calls for rest.

TO SET PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. ENTER "1 OR 2 OR 3" FOR FIRST SECOND OR THIRD PENALTY
3. PRESS "2:00" MINUTE BUTTON OR ENTER DESIRED TIME AND THEN "ENTER".

TO CLEAR PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "CLR, CLR, CLR" TILL SCREEN CLEARED
3. PRESS "GAME TIME"

TO CLEAR GOALS

1. PRESS "HOME OR VISITOR SCORE"
2. PRESS "CLEAR"

TO QUIT SHOT CLOCK

1. PRESS "PLAY TIMER SET"
2. PRESS CLEAR
3. PRESS "PLAY TIMER RESET"
4. PRESS "GAME TIME" AND YOU ARE NOW IN REGULAR GAME MODE.