

OPERATOR'S INSTRUCTIONS – BLACKBURN RINK

IMPORTANT, LOOK AT SCREEN WHILE PROGRAMMING, NOT WALL CLOCK!

*****NOTE YOUR ENTRY MUST BE DONE QUICKLY OR IT WILL TIME OUT*****

DISPLAY SCREEN

HOME SCORE	VISITOR SCORE	2:00	GAME TIME	INT MODE	7	8	9	HORN
HOME PNLTY	VISITOR PNLTY	5:00	NEW GAME	PERIOD	4	5	6	
HOME SHOTS	VISITOR SHOTS	10:00	PLAY TIMER SET	SHIFT	1	2	3	RUN STOP
+ 1	XXXXXX	20:00	PLAY TIMER RESET	SETUP	CLEAR	0	ENTER	

TO SET TIME CLOCK

1. PRESS "GAME TIME"
 2. PRESS "CLR, CLR, CLR" TO CLEAR OLD ENTRY
 3. ENTER TIME YOU NEED AS 2 OR 15 OR 20
 4. PRESS "ENTER"
- *NOTE, TIMER MUST

TO SET PERIOD

1. PRESS "PERIOD"
2. ENTER PERIOD NUMBER "1" OR "2"
3. PRESS "ENTER"

TO SET GOALS

1. PRESS "HOME" OR "VISITOR SCORE"
2. PRESS "+1" AFTER EACH GOAL SCORED

TO SET SHOT CLOCK

1. PRESS "PLAY TIMER SET"
 2. ENTER "30" THEN PRESS "ENTER"
- Note there is no remote for this clock it is done on the control box by pressing "PLAY TIMER RESET" every time the referee calls for rest.

TO SET PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "1 OR 2 OR 3" FOR FIRST SECOND OR THIRD PENALTY & PRESS "ENTER".
3. PRESS "2:00" MINUTE BUTTON OR ENTER DESIRED TIME AND THEN "ENTER".

TO CLEAR PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "CLR, CLR, CLR" TILL SCREEN CLEARED
3. PRESS "GAME TIME"

TO CLEAR GOALS

1. PRESS "HOME OR VISITOR SCORE"
2. PRESS "CLEAR"

TO QUIT SHOT CLOCK

1. PRESS "PLAY TIMER SET"
2. PRESS CLEAR
3. PRESS "PLAY TIMER RESET"
4. PRESS "GAME TIME" AND YOU ARE NOW IN REGULAR GAME MODE.